

SISCO**WOOD**

DENSITY METER

AS-120DEN

2. FEATURES

- * Designed to determine the indentation density of wood.
- * Used the exclusive Micro-computer LSI circuit and crystal time base to offer high accuracy measurement.
- * Digital display gives exact reading with no guessing or errors.
- * Can communicate with PC for recording, printing and analysing by the optional software and cable for USB interface.
- * Automatic power off to conserve power.
- * Use operation stand of optional parts can get good accuracy and repetitiveness due to constant measurement force to eliminate the errors caused by artificially applied different force.

2. SPECIFICATIONS

- Display: 4 digits, 10 mm LCD
 Display Range: Density value/average/maximum
 Measurement Range : 0.01g/cm³~1.2g/cm³
 Resolution: 0.01g/cm³
 Measurement deviation: $\leq \pm 0.01\text{g/cm}^3$
 Power supply: 2 size 7 battery
 Operating condition: Temp. 0°C~50°C

Humidity <80%

Size: 162mm*65mm*28mm
 (6.4inch*2.6inch*1.1inch)

Weight: about 170g(not including batteries)

PC interface: USB interface

Power off: 2 modes

Manual off at any time by depressing the power key till OFF shows on the display or Auto power off after 2 minutes from last key operation.

Accessories:

- Carrying case1 pc.
 Operation manual1 pc.

NOTE: this test block is not the real density test sample. It is only an imitation. Just place the block onto a flat glass , then place the point of indenter into the hole of the block when take measurements.

Optional accessory:

- Cable and software for USB
 Operating Stand

3. FRONT PANEL DESCRIPTIONS



- 3-1 Sensor
 3-2 Display
 3-3 Power key
 3-4 Max hold key
 3-5 Zero key
 3-6 N/Average key
 3-7 USB interface
 3-8 CAL key
 3-9 Indicator of Max. Value
 3-10 Indicator of Average value
 3-11 State of average value
 3-12 Number of measurements in the state of average value

4. MEASURING PROCEDURE

4.1 Test specimen

The minimum thickness is specified in a different standard, see part 1. Specimen should allow measurement to be taken at least 12 mm from any edge. Specimen surface should be flat and parallel to allow the presser face to contact to the specimen over an area which has a minimum radius of 6mm from the durometer probe. The specimen may be constructed with layered pieces to achieve the necessary thickness requirements, however measurements taken on these specimens may not agree with those made on solid specimens, due to the surface faces between layers not being in complete contact.

4.2 Depress and release the "Power key" to power the tester on.

4.3 Depress the "MAX" key till the mark MAX shows on the display.

4.4 Hold the durometer vertically with the point of the indenter at least 12 mm from any edge. Apply the presser foot to the specimen as rapidly as possible, without shock, keeping the foot parallel to the surface of the specimen. Apply just sufficient force to

obtain firm contact between the presser foot and the specimen. Hold for 1 or 2 seconds, the maximum reading can be obtained automatically.

4.5 To take the next measurement, just depress the "Zero key" and repeat 4.4. On the other hand, you can depress the "Max hold key" till the mark MAX disappears from the display. And then repeat the step 4.3 and 4.4.

4.6 If other than a maximum reading is needed, no need to set the mark "MAX" showing on the display. In such case, the reading on the display is an instant value. Just hold the durometer in place without motion and obtain the reading after the required time interval (Normally less than 1 second).

4.7 How to take average value

4.7.1 To take the average value of many times of measurements, just depress and release the "N/AVE key" to make the symbol "N" showing on the display, followed by a digit between 1-9 with the prefix "No.". Here the digit is the times of measurements used to calculate the average value. Every time depress and release the "N/AVE key", the digit will increase 1. And the digit will become "1" while depressing the "N/AVE

key" at "9".

4.7.2 Adjust the digit to the number needed and depress "MAX key" or "Zero key" to return to the measurement state or wait for several seconds till "0" on the display.

4.7.3 Take measurements as per steps from 4.3 to 4.5. Be sure that every test should be 6 mm apart. Every time take a measurement, the reading and the times of measurements show on the display. When the times of measurements is equal to the number set, the unit first displays the reading of the last , and then display the average value of last "N" measurements, followed by 2 beeps, with a symbol "AVE" indicating on the display.

4.7.4 To take the next average value, just repeat 4.7.3.

4.7.5 To release from average measurement, just depress the "N/AVE" till "N" disappears.

5. CALIBRATION CHECK

To check whether the tester is accurate, just Insert the indenter into the hole of the calibrated test Block. Apply enough force to make firm contact between the top surface of the test block and the presser foot. The reading should agree with the

value stamped on the test block. If not, just carry out Zero calibration and High end calibration.

5.1 Zero calibration

Hold the durometer vertically with the point of the indenter hanging in the air, the reading on the display should be "0". If not, depress the "Zero key" to make the tester display "0".

5.2 High end calibration

Just place the indenter onto a flat glass, apply enough force to make firm contact between the glass and the presser foot. The readings on the display should lie between 1.98 and 1.21 . If not, press "CAL key" to carry out high end calibration.

6. BATTERY REPLACEMENT

6.1 When the battery symbol appears on the display, it is time to replace the batteries.

6.2 Slide the Battery Cover away from the tester and remove the batteries.

6.3 Install batteries paying careful attention to polarity.