

°C / °F Digital thermometer manual

A. precautions

- 1. This product is equipped with a built-in lithium battery, which cannot be directly thrown into a fire after use to prevent explosion and personal injury.
- 2. This product is a specialized product for fish tanks and cannot be used for other purposes.
- 3.This product is intended for use on the surface of a fish tank and cannot be placed in water or in a drenched environment.
- 4.This product can only be charged with a DC5V power supply, otherwise it will damage the product. In severe cases, other safety issues may occur.
- 5.If the product malfunctions, please contact the merchant for resolution and cannot disassemble it on your own.

B.Instructions for use

- 1.Tear off the Double-sided tape protective paper on the back of the product, and stick the thermometer 3CM below the water surface line outside the cylinder. (Observation data is more accurate after 15 minutes of charging and newly installed thermometer)
- 2. After receiving the product, please charge it until it shows FUL full charge.
- 3.Low battery display LO., Full charge display FUL, charge display E-3
- 4. The touch switch \cup can switch the product on and off, and comes with a 30 second automatic shutdown function.
- 5.Under wake-up mode, touch \circlearrowleft the button for 3 seconds to switch $^{\circ}$ C / $^{\circ}$ F mode.

C.Parts Catalogue

| Component Name | number |
|--------------------|--------|
| thermometer | 1 |
| USB Charging cable | 1 |
| instructions | 1 |

